

DISINFECTANTS AND CLEANERS LIST 2021

Test protocol :

1. The test was carried out with the highest recommended concentration applied 10 times
2. The user guide of the cleaning agent must be considered in all cases. A damage of the padding material after a long term usage is not impossible overtime. Please contact us in this case.


Serge Ferrari

PRODUCT NAME	BRAND NAME	DISINFECTANT	ANTI CORONAVIRUS ACTIVE	CLEANER ONLY	AMOUNT OF SOLUTION USED	TESTED ON						TEST RESULT
						STAMSKIN			BATYLINE			
						Top	Zen	One	Iso	Duo	Eden	
Quant Desinfectant	3M	x	x		0,39%	x	x	x	x	x	x	✔ OK
Biguacid Liquid	ANTISEPTICA	x			Pure	x	x	x	x	x	x	✘ NOT OK
Biguacid-S	ANTISEPTICA	x			HDZ	x	x	x	x	x	x	✔ OK
SteriMax Wipes	ASEPTIX	x			Tissues	x	x	x	x	x	x	✔ OK
Hexaquant plus lemon fresh	B. BRAUN MEDICAL AG	x			Pure			x				✔ OK
Hexaquant plus lemon fresh	B. BRAUN MEDICAL AG	x			Pure	x	x		x	x	x	✘ NOT OK
Hexaquant plus lemon fresh	B. BRAUN MEDICAL AG	x			0,5% dilution	x	x	x	x	x	x	✔ OK
Meliseptol Foam pure	B. BRAUN MEDICAL AG	x			Ready to use solution	x	x	x	x	x	x	✔ OK
Birex Se	BIOTROL TM	x			2,5% dilution	x	x	x	x	x	x	✔ OK
Bacillol 30 Foam	BODE CHEMIE	x			Pure	x	x	x				✔ OK
Bacillol 30 Foam	BODE CHEMIE	x			Pure				x	x	x	✘ NOT OK
Bacillol 30 tissues	BODE CHEMIE	x	x		Tissues	x	x	x	x	x	x	✔ OK
Microbac Tissues	BODE CHEMIE	x			Tissues	x	x	x	x	x	x	✔ OK
Browning Treatment	CHEMICAL SPECIALITIES MANUFACTUREING CORP.			x	Pure	x	x	x	x	x	x	✔ OK
Leather Cleaner	CHEMSPEC	x			Ready to use solution	x	x	x	x	x	x	✔ OK
Bleach Germicidal Wipes	CLOROX	x			Tissues	x	x	x	x	x	x	✔ OK
Broad Spectrum	CLOROX	x			Ready to use solution	x	x	x	x	x	x	✔ OK

> Can't find your product in the list? Please feel free to contact us for testing!

PRODUCT NAME	BRAND NAME	DISINFECTANT	ANTI CORONAVIRUS ACTIVE	CLEANER ONLY	AMOUNT OF SOLUTION USED	TESTED ON						TEST RESULT
						STAMSKIN			BATYLINE			
						Top	Zen	One	Iso	Duo	Eden	
Citrace Disinfectant & Deodorizer	CLOROX	x			Ready to use solution			x				✔ OK
Citrace Disinfectant & Deodorizer	CLOROX	x			Ready to use solution	x	x		x	x	x	✘ NOT OK
Colorox	CLOROX	x			5% dilution	x	x	x	x	x	x	✔ OK
Disinfecting Wipes	CLOROX	x			Tissues	x	x	x	x	x	x	✔ OK
Dispatch Hospital Cleaner Desinfectant Towels	CLOROX	x			Tissues	x	x	x	x	x	x	✔ OK
Fuzion Cleaner - Desinfectant	CLOROX	x			Ready to use solution	x	x	x	x	x	x	✔ OK
Hydrogen Peroxide	CLOROX	x			Ready to use solution	x	x	x	x	x	x	✔ OK
Maya Soft	CWK - SCS			x	10%	x	x	x	x	x	x	✔ OK
Acticide 02 RTU	DALTA	x			Ready to use solution	x	x	x	x	x	x	✔ OK
Glance Glass and Surface Cleaner	DIVERSEY			x	Ready to use solution	x	x	x	x	x	x	✔ OK
Oxivir Plus Spray	DIVERSEY	x			Pure	x	x	x				✔ OK
Oxivir Plus Spray	DIVERSEY	x			Pure				x	x	x	✘ NOT OK
Oxivir Tb	DIVERSEY	x			Ready to use solution	x	x	x	x	x	x	✔ OK
Oxivir Tb Wipes	DIVERSEY	x			Tissues	x	x	x	x	x	x	✔ OK
Virex II 256	DIVERSEY	x			0,39%	x	x	x	x	x	x	✔ OK
Power Clean	DKL GMBH	x			Pure	x	x	x	x	x	x	✘ NOT OK
Pro Pad	DKL GMBH	x			Pure				x	x	x	✘ NOT OK

> Can't find your product in the list? **Please feel free to contact us for testing!**

PRODUCT NAME	BRAND NAME	DISINFECTANT	ANTI CORONAVIRUS ACTIVE	CLEANER ONLY	AMOUNT OF SOLUTION USED	TESTED ON						TEST RESULT
						STAMSKIN			BATYLINE			
						Top	Zen	One	Iso	Duo	Eden	
Pro Pad	DKL GMBH	x			Pure	x	x	x				✔ OK
Favorit wet wipes Bio	DR. DEEPE GMBH, MULTI-COM GMBH			x	Tissues	x	x	x	x	x	x	✔ OK
Foemix	DR. SCHNELL CHEMIE GMBH			x	Ready to use solution	x	x	x	x	x	x	✘ NOT OK
Glasam	DR. SCHNELL CHEMIE GMBH			x	Ready to use solution	x	x	x	x	x	x	✘ NOT OK
Schirocco Clean	DR. SCHNELL CHEMIE GMBH			x	Ready to use solution	x	x	x	x	x	x	✔ OK
Biguanid Fläche N	DR SCHUMACHER	x	x		Pure	x	x	x	x	x	x	✔ OK
Cleanisept	DR SCHUMACHER	x	x		Pure	x	x	x	x	x	x	✔ OK
Cleanisept Wipes Maxi	DR SCHUMACHER	x	x		Tissues	x	x	x	x	x	x	✔ OK
Descosept sensitive wipes	DR SCHUMACHER	x	x		Tissues	x	x	x	x	x	x	✔ OK
Optisal N	DR SCHUMACHER	x			5%	x	x	x				✔ OK
Optisal N	DR SCHUMACHER	x			0,05				x	x	x	✘ NOT OK
Optisal Plus	DR. SCHUMACHER GMBH	x	x		5%	x	x	x	x	x	x	✔ OK
FD 360	DÜRR DENTAL	x			Pure	x	x	x				✘ NOT OK
FD 360	DÜRR DENTAL	x			Pure				x	x	x	✔ OK
FD 360	DÜRR DENTAL	x			Ready to use solution	x	x	x	x	x	x	✔ OK
FD 366	DÜRR DENTAL			x	Pure	x	x	x	x	x	x	✔ OK
Asepticare TB+II	ECOLAB	x			Ready to use solution	x	x	x	x	x	x	✔ OK

> Can't find your product in the list? Please feel free to contact us for testing!

PRODUCT NAME	BRAND NAME	DISINFECTANT	ANTI CORONAVIRUS ACTIVE	CLEANER ONLY	AMOUNT OF SOLUTION USED	TESTED ON						TEST RESULT
						STAMSKIN			BATYLINE			
						Top	Zen	One	Iso	Duo	Eden	
Diesin HG	ECOLAB	x			2%	x	x	x				✔ OK
Diesin HG	ECOLAB	x			0,02				x	x	x	✘ NOT OK
Dishguard 72	ECOLAB	x			5%	x	x	x	x	x	x	✔ OK
Incidin Extra N	ECOLAB	x			0,5%	x	x	x	x	x	x	✔ OK
Incidin Pro	ECOLAB	x			0,25%	x	x	x	x	x	x	✔ OK
Incidin Pro	ECOLAB	x			0,5%	x	x	x	x	x	x	✔ OK
Incidin Rapid	ECOLAB	x			5%	x	x	x	x	x	x	✘ NOT OK
Incidin Rapid	ECOLAB	x			0,05	x	x	x	x	x	x	✘ NOT OK
Klercide	ECOLAB	x			Ready to use solution			x				✔ OK
Klercide	ECOLAB	x			Ready to use solution	x	x		x	x	x	✘ NOT OK
Oasis 146 (Multi-Quant Sanitizer)	ECOLAB	x			5%	x	x	x	x	x	x	✔ OK
Oasis 146 (Multi-Quant Sanitizer)	ECOLAB	x			Pure			x				✔ OK
Oasis 146 (Multi-Quant Sanitizer)	ECOLAB	x			Pure	x	x		x	x	x	✘ NOT OK
Oxy Cide	ECOLAB	x			Pure	x	x	x	x	x	x	✔ OK
Oxy Cide	ECOLAB	x			We abide the dilution written on the bottle [2.3%]	x	x	x	x	x	x	✔ OK
Laquick Pro	ECO-POINT	x	x		Ready to use solution	x	x	x	x	x	x	✔ OK

> Can't find your product in the list? **Please feel free to contact us for testing!**

PRODUCT NAME	BRAND NAME	DISINFECTANT	ANTI CORONAVIRUS ACTIVE	CLEANER ONLY	AMOUNT OF SOLUTION USED	TESTED ON						TEST RESULT
						STAMSKIN			BATYLINE			
						Top	Zen	One	Iso	Duo	Eden	
BioSafe	ECO-POINT			x	Ready to use solution	x	x	x	x	x	x	✔ OK
Freka-Nol N	FRESENIUS MEDICAL CARE	x			Pure	x	x	x	x	x	x	✔ OK
ClearSurf	FRESENIUS MEDICAL CARE	x			1%				x	x	x	✔ OK
Clinell Universal Spray	GAMA HEALTHCARE	x	x		Ready to use solution	x	x	x	x	x	x	✔ OK
Globaclean	GLOBASID	x			40%	x	x	x	x	x	x	✔ OK
Dismozon Plus	HARTMANN	x			Pure	x	x	x	x	x	x	✔ OK
Mikrobac forte	HARTMANN	x	x		Pure	x	x	x	x	x	x	✔ OK
Dismozon pur	HARTMANN	x			10%	x	x	x	x	x	x	✔ OK
Sterillium	HARTMANN	x			Ready to use solution			x				✘ NOT OK
Sterillium Gel	HARTMANN	x			Ready to use solution			x				✘ NOT OK
Safe Sept	HENRY SCHEIN	x			Pure	x	x	x	x	x	x	✘ NOT OK
Hüsella top fit	HÜSER VAN ZWOLL			x	0,4	x	x	x	x	x	x	✘ NOT OK
All Clean	JOLI	x			Rein	x	x	x	x	x	x	✔ OK
Surface Sanitizer	KAY CHEMICAL	x			Pure	x	x	x	x	x	x	✔ OK
Clese Pure	KLEISER MEDICAL	x			Pure	x	x	x	x	x	x	✔ OK
Detergent Disinfectant Surfaces Hautes (DDSH)	LABORATOIRES ANIOS	x			Pure	x	x	x				✔ OK
Detergent Disinfectant Surfaces Hautes (DDSH)	LABORATOIRES ANIOS	x			Pure				x	x	x	✘ NOT OK

> Can't find your product in the list? **Please feel free to contact us for testing!**

PRODUCT NAME	BRAND NAME	DISINFECTANT	ANTI CORONAVIRUS ACTIVE	CLEANER ONLY	AMOUNT OF SOLUTION USED	TESTED ON						TEST RESULT
						STAMSKIN			BATYLINE			
						Top	Zen	One	Iso	Duo	Eden	
Mousse Detergente des surfaces	LABORATOIRES ANIOS	x			Pure	x	x	x	x	x	x	✔ OK
Nettoyant Désinfectant Multisurface	LABORATOIRES ANIOS	x			Pure	x	x	x				✔ OK
Surfa'Safe	LABORATOIRES ANIOS	x			Pure	x	x	x	x	x	x	✔ OK
WIP Anios Premium	LABORATOIRES ANIOS	x			Pure	x	x	x				✔ OK
X-Spray	LABORATOIRES ANIOS			x	Pure	x	x	x	x	x	x	✘ NOT OK
Umonium Medical Spray	LABORATOIRE HUCKERTS	x			Ready to use solution	x	x	x	x	x	x	✔ OK
Desinfecting Wipes	LYSOL	x	x		Tissues	x	x	x	x	x	x	✔ OK
Kitchen Cleaner	LYSOL			x	Ready to use solution	x	x	x	x	x	x	✔ OK
Cavicide	METREX	x	x		Ready to use solution			x	x	x	x	✔ OK
Cavicide	METREX	x	x		Ready to use solution	x	x					✘ NOT OK
Cavi Wipes	METREX	x	x		Tissues	x	x	x	x	x	x	✔ OK
Fresh Breeze - TB	MPC MISCO PRODUCTS CORPORATION			x				x				✔ OK
Fresh Breeze - TB	MPC MISCO PRODUCTS CORPORATION			x		x	x		x	x	x	✘ NOT OK
Dr. Schumacher GmbH	OPTISAL PLUS							x				✔ OK
Sani-Cloth AF3	PDI	x	x		Tissues	x	x	x	x	x	x	✔ OK
Sani-Cloth PLUS	PDI	x			Tissues	x	x	x	x	x	x	✔ OK
Sani - Cloth Super	PDI	x	x		Tissues	x	x	x				✔ OK

> Can't find your product in the list? **Please feel free to contact us for testing!**

PRODUCT NAME	BRAND NAME	DISINFECTANT	ANTI CORONAVIRUS ACTIVE	CLEANER ONLY	AMOUNT OF SOLUTION USED	TESTED ON						TEST RESULT
						STAMSKIN			BATYLINE			
						Top	Zen	One	Iso	Duo	Eden	
Sani - Cloth Super	PDI	x			Tissues				x	x	x	✗ NOT OK
Advanced Hand Sanitizer	PURELL	x			Pure			x				✓ OK
Advanced Hand Sanitizer	PURELL	x			Pure	x	x		x	x	x	✗ NOT OK
Hand Sanitizing Wipes	PURELL	x			Tissues	x	x	x	x	x	x	✓ OK
FADE -A- DYNE II	RUSS MEDICAL SPECIALTIES			x	Pure	x	x	x	x	x	x	✓ OK
Sanizide	SAFETEEC	x			Ready to use solution	x	x	x	x	x	x	✓ OK
Antifect AF	SCHÜLKE					x	x	x	x	x	x	✓ OK
Kodan wipes	SCHÜLKE	x			Tissues	x	x	x	x	x	x	✗ NOT OK
Mikrozyd sensitive wipes	SCHÜLKE	x			Tissues	x	x	x	x	x	x	✓ OK
Mikrozyd universal wipes premium	SCHÜLKE	x			Tissues	x	x	x	x	x	x	✓ OK
Terraline Protect	SCHÜLKE	x			5%	x	x	x	x	x	x	✓ OK
Terraline Protect	SCHÜLKE	x			0,5%	x	x	x	x	x	x	✓ OK
Antifect Extra	SCHÜLKE +	x			Pure	x	x	x	x	x	x	✓ OK
Terralin Protect	SCHÜLKE +	x			Pure	x	x	x	x	x	x	✗ NOT OK
Polsterclean	SCHUPP GMBH			x	Ready to use solution	x	x	x	x	x	x	✓ OK
Cleaner 500	SERGE FERRARI			x	Ready to use solution	x	x	x	x	x	x	✓ OK
Coverage Spray HB Plus	STERIES CORPORATION	x	x		Ready to use solution	x	x	x	x	x	x	✓ OK

> Can't find your product in the list? Please feel free to contact us for testing!

PRODUCT NAME	BRAND NAME	DISINFECTANT	ANTI CORONAVIRUS ACTIVE	CLEANER ONLY	AMOUNT OF SOLUTION USED	TESTED ON						TEST RESULT
						STAMSKIN			BATYLINE			
						Top	Zen	One	Iso	Duo	Eden	
Hydrogen Peroxide	SWAN	x			Ready to use solution	x	x	x	x	x	x	✔ OK
Isopropyl Alcohol	SWAN	x			Pure	x	x	x	x	x	x	✘ NOT OK
Boat Master "Sky Care Kit"	UNITERS SPA	x			Pure			x				✔ OK
Rescue	VITROX TECHNOLOGIE INC.	x			Pure			x				✔ OK
Rescue	VITROX TECHNOLOGIE INC.	x			Pure	x	x		x	x	x	✘ NOT OK
Rescue	VITROX TECHNOLOGIE INC.	x	x		5,9% dilution	x	x	x	x	x	x	✔ OK
Rheosept	WACHENDORFF-CHEMIE	x			Pure	x	x	x	x	x	x	✔ OK
Clean'n Easy	WECOLINE	x			Ready to use solution	x	x	x	x	x	x	✔ OK
Wexcide 128	WEXFORD LABS	x			Pure			x				✔ OK
Wexcide 128	WEXFORD LABS	x			Pure	x	x		x	x	x	✘ NOT OK

> Can't find your product in the list? **Please feel free to contact us for testing!**